

#1

-Stack 1× HEPA and 1× square $\geq 4"$ MERV4 filters.



#2

- Carefully remove the vent and 1× round 3.5" MERV4 filter from the supply port.
- Carefully insert the stacked filters to fit into the end of the supply port.



#3

-Carefully insert the vent with its elastic band into the supply port.

